



CSP-1R Reloading Adapter for S-press



The CSP-1R reloading adapter for the S-press adapts the 5/8-24 threaded ram to hold a standard RCBS-style button shell holder.

It also extends the position of the shell holder so it is at the top of the press base in the down position, and provides for an angled spent primer port dropping spent primers into the CSP-1T primer tray.

One adapter is provided free with each press. Additional adapters may be purchased for replacement purposes.



The adapter features a ball/spring detent to tension and hold the shell holder securely and yet allow easy removal. The threads of the shell holder adapter and press rams are synchronized to position the slot toward the press front.

If used on a press not synchronized with the adapter, you can use an O-ring to position the slot toward the front.



CSP-1R Reloading Adapter for S-press



The CSP-1R reloading adapter for the S-press adapts the 5/8-24 threaded ram to hold a standard RCBS-style button shell holder.

It also extends the position of the shell holder so it is at the top of the press base in the down position, and provides for an angled spent primer port dropping spent primers into the CSP-1T primer tray.

One adapter is provided free with each press. Additional adapters may be purchased for replacement purposes.



The adapter features a ball/spring detent to tension and hold the shell holder securely and yet allow easy removal. The threads of the shell holder adapter and press rams are synchronized to position the slot toward the press front.

If used on a press not synchronized with the adapter, you can use an O-ring to position the slot toward the front.

